

Deck Washer™

Flow-Through Brush

- Prep your deck for staining or sealing
- Scrubbing Broom with Water Jet Nozzles connects to a garden hose
- 2 tools in 1

Step 1:

Screw handle C817494 to the brush head C817493.

Step 2:

Connect remaining two handles C817495 (A) and C817496 (B) to handle C817494 already attached to brush.

Step 3:

Connect soap injector C817508 to the end of handle C817496 (B). Connect water valve C817497 to end of soap injector C817508. Connect garden hose to valve C817497, move to closed position.

Step 4:

Move blue control on soap injector to open position and pull out to pour soap into injector. Once soap is in soap injector replace blue control and move to either water or soap position. Open valve C817497 to start water flow and begin scrubbing.



HOMERIGHT®



Register your product at
www.homeright.com

HomeRight

1661 94th Lane N.E., Minneapolis, MN 55449-4324
P: 763-780-5115 · Customer Service Line: 1-800-264-5442
8:00 a.m. to 5:00 p.m. CST

PN C820512 Rev A 3/12

